486 System (A1G4)

User's Guide

100% Recycled Paper

Downloaded from www.Manualslib.com manuals search engine

Copyright

Copyright © 1995 by this company. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of this company.

Disclaimer

This company makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not this company, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, this company reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

Intel is a registered trademark of Intel Corporation.
IBM is a registered trademark and PS/2 is a trademark of International Business Machines Corporation.
MS-DOS is a registered trademark of Microsoft Corporation.

Other brand and product names are trademarks and/or registered trademarks of their respective holders.

Downloaded from www.Manualslib.com manuals search engine

About this Manual

Purpose

This user's guide aims to give you all the information you need to operate the system properly.

Manual Structure

This user's guide consists of two chapters as follows:

Chapter 1 System Board

This chapter describes the system board and all its major components. It contains the system board layout, jumper settings, cache and memory configurations, and other internal devices.

Chapter 2 BIOS Utility

This chapter explains the system BIOS and tells how to configure the system by setting the BIOS parameters.

Downloaded from www.Manualslib.com manuals search engine

Conventions

The following conventions are used in this manual:

`Text entered by user`	Represents text input by the user.
`Screen messages`	Denotes actual messages that appear onscreen.
ALT, ENTER, F8, etc.	Represent the actual keys that you have to press on the keyboard.
	NOTE Gives bits and pieces of additional information related to the current topic.
	WARNING Alerts you to any damage that might result from doing or not doing specific actions.
	CAUTION Suggests precautionary measures to avoid potential hardware or software problems.
	IMPORTANT Reminds you to take specific action relevant to the accomplishment of the procedure at hand.
	TIP Tells how to accomplish a procedure with minimum steps through little shortcuts.

Downloaded from www.Manualslib.com manuals search engine

Table of Contents

Chapter 1 System Board

1.1 System Board Layout 1-2
1.2 ESD Precautions 1-4
1.3 Pre-installation Instructions 1-4
1.4 Jumper Settings 1-5
1.5 Installing Memory 1-8
1.5.1 Installing a SIMM 1-9
1.5.2 Removing a SIMM 1-10
1.5.3 Reconfiguring the System 1-10
1.6 Upgrading the CPU 1-11
1.6.1 Unpacking the Upgrade CPU 1-11
1.6.2 Installing the Upgrade CPU 1-11
1.7 Power Daughter Board 1-13
1.8 Upgrading VGA Memory 1-14
1.9 Upgrading Cache Memory 1-16
1.10 Post-installation Instructions 1-17
1.11 Power-Management Feature 1-18
1.12 Advanced Power Management (APM) 1-21
1.13 Intel SL-Enhanced CPU 1-22
1.14 VESA DPMS 1-22
1.15 Error Messages 1-23
1.15.1 Software Error Messages 1-23
1.15.2 System Error Messages 1-23
1.15.3 Correcting Error Conditions 1-26

Downloaded from www.Manualslib.com manuals search engine

Chapter 2 BIOS Utility

2.1 Entering Setup 2-2
2.2 Basic System Configuration 2-3
2.2.1 Date and Time 2-5
2.2.2 Diskette Drives 2-6
2.2.3 IDE Fixed Disk Drives 2-6
2.2.4 System Memory 2-9
2.2.5 Math Coprocessor 2-9
2.2.6 Video Display 2-10
2.2.7 Communication Status 2-10
2.2.8 Enhanced IDE Features 2-11
2.2.9 Num Lock After Boot 2-12
2.2.10 Memory Test 2-12
2.2.11 Auto-Configuration Mode 2-12
2.2.12 Fast Boot Mode 2-12
2.3 Advanced System Configuration 2-13
2.3.1 Shadow RAM 2-13
2.3.2 System Cache 2-14
2.3.3 System Speed 2-14
2.3.4 Memory at 15MB-16MB 2-14
2.4 Power-Saving Configuration 2-15
2.4.1 Power-Management Mode 2-16
2.4.2 Monitored Activities 2-18

Downloaded from www.Manualslib.com manuals search engine

2.5 System Security Setup 2-19
2.5.1 Disk Drive Control 2-19
2.5.2 Onboard Communication Ports 2-21
2.5.3 Setup Password 2-23
2.5.4 Power-On Password 2-24
2.6 Load Setup Default Settings 2-25
2.7 Leaving Setup 2-26
2.8 Fixed Disk Types 2-27

Downloaded from www.Manualslib.com manuals search engine

List of Figures

1-1 System Board Layout 1-3
1-2 Jumper Locations 1-5
1-3 Installing a SIMM 1-9
1-4 Removing a SIMM 1-10
1-5 Pin 1 Indicator on the Upgrade CPU and Socket 1-12
1-6 Installing an Upgrade CPU 1-12
1-7 Installing VGA RAM 1-15
1-8 Installing Cache 1-16

List of Tables

1-1 System Board Jumpers 1-6
1-2 CPU Clock Selection 1-6
1-3 CPU Type Selection 1-7
1-4 Cache RAM Size Selection 1-7
1-5 Memory Configurations 1-8
1-6 Cache Size Options and Chip Locations 1-16
1-7 Power-Management Modes 1-20
1-8 VESA DPMS Modes 1-22
1-9 System Error Messages 1-24
2-1 IDE Fixed Disk Configurations 2-6
2-2 Drive Control Parameters 2-20
2-3 Serial Port 1 Parameters 2-21
2-4 Serial Port 2 Parameters 2-21
2-5 Parallel Port Control Parameters 2-22
2-6 Fixed Disk Types 2-27

Downloaded from www.Manualslib.com manuals search engine